



**Resilience Content Filtering Appliance  
with Websense® Web Security™ v7**

**Version 7.0.1**

**Quick Reference Guide**

**Resilience Technology Corporation**

7502 Connelly Drive  
Suite 101  
Hanover, MD 21076

Tel: 888.297.8515  
International: 650-230-2200  
Fax: 888.297.8515

[www.resilience.com](http://www.resilience.com)  
[support@resilience.com](mailto:support@resilience.com)



## OVERVIEW

This document provides an overview of the information needed to install and begin the configuration of your Resilience Content Filtering Appliance. Complete information about the software setup process is available in the Websense documentation, downloadable from [www.websense.com](http://www.websense.com).

## PREPARING FOR INSTALLATION

1. Unpack and inspect the CWR unit for damage that may have occurred during shipment.
2. Save all packing slips and documents included with the unit. Save the shipping cartons and packing materials until you have completed the installation and verified proper operation.
3. Make sure that you have received all items ordered. Your shipment should consist of the following:

### •Resilience CWR 20 or 30 Models

- 1 box containing the appliance module
- An accessory kit that includes the following:
  - Installation bag:
    - 4 rubber feet
    - 2 rack ears
    - 6 small ear mounting screws
  - Power bag:
    - 1 power cord
  - Communications bag:
    - 1 DB-9 serial console cable
    - 1 Category-5 Ethernet crossover cable for local configuration
  - Documentation:
    - This Quick Reference Guide
    - CD Containing Software Documentation
    - Resilience Software Release Notes
    - End User License Agreement
    - Limited Warranty

### •Resilience CWR 7200/7300 models:

- 1 box containing the CWR appliance
- An accessory kit that includes the following:
  - 2 rack mounting ears and screws
  - Rack rail kit: (Optional)
    - Left and right rack rails
    - Rear stabilization bar
    - 2 rack retention ears
    - 8 #6 screws for rail assembly
    - 8 #8 screws to attach retention ears
  - Power bag:
    - 1 power cord
  - Communications bag:
    - 1 DB-9 serial console cable
    - 1 Category-5 Ethernet crossover cable for local configuration



- Documentation: (1 per system)
  - Quick Reference Guide
  - CD Containing Software Documentation
  - Resilience Software Release Notes
  - Rack Rail Installation Guide
  - End User License Agreement
  - Limited Warranty
  
- CWR 8100 models:**
  - 1 box containing the Resilience CWR appliance(s)
  - An accessory kit that includes the following:
    - 1 power cord
    - 1 serial console cable
    - Product Information Guide
  - Documentation Kit:
    - Quick Reference Guide
    - CD Containing Software Documentation
    - Resilience Software Release Notes
    - End User License Agreement
    - Limited Warranty
  - Rack rail kit and installation instructions

## *Quick Reference Guide (Resilience CWR Family)*

### **Installation Steps**

1. Attach the rack ears, rails, or feet.
2. Install the module into the rack and attach the power cord.
3. Using the diagram on the back pages of this guide, attach a network crossover cable from the port eth1 (for CWR 20 or 30 systems), eth7a (for all 7000 series systems) or eth0a (labeled port 1 for 8100 systems) labeled “Network Management” on the module to the system that will be performing the initial Web setup.
4. Begin the system configuration by powering on the module and establishing a web connection to “http://192.168.0.1” and stepping through the guided configuration

**Note:** *For detailed instructions on the rest of the installation, follow the instructions in chapters 2 and 3 of the CWR Installation Guide.*

5. When initial configuration of the module is complete and the module has been halted, connect main network cables to the module.

**Note:** *For installations of Network Agent only, be sure that the other installations are installed and active before activating the configuration.*

6. Complete Websense configuration by following the instructions in chapter 4 of the CWR Installation Guide.
7. Before using the product to filter web content, you must have your Websense subscription key available. You can obtain an evaluation key at [www.websense.com/Downloads](http://www.websense.com/Downloads). This key is required for downloading the Websense Master Database, which is required for filtering.

**Note:** *After installation of all components is complete, refer to the Websense Administrator’s Guide for detailed configuration and setup options. Websense documents are downloadable from*

*[www.websense.com](http://www.websense.com).*

9. Complete the online registration at:  
<http://www.resilience.com/registration>

# PORTS AND CABLING WORKSHEETS

## Resilience CWR 7000 Series Cabling Worksheet


	a	b	c	d
0				
2				
3				
4				
5				
6				
7	Management			

		Slot 2	Slot 3	Slot 4	Slot 5	Slot 6	Slot 7
eth0a   eth0b		Ports 2d	Ports 3d	Ports 4d	Ports 5d	Ports 6d	
		2c	3c	4c	5c	6c	eth7a
		2b	3b	4b	5b	6b	
		2a	3a	4a	5a	6a	RESlink

# Resilience CWR 20/30

## Cabling Worksheet


<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>	<b>8</b>



# Resilience CWR 8102

## Cabling Worksheet


	<b>A</b>	<b>B</b>	<b>c</b>	<b>d</b>
<b>0</b>				
<b>1</b>				



# Resilience CWR 8104/8108

## Cabling Worksheet

	a	b	c	d
<b>0</b>				
<b>1</b>				
<b>2</b>				



### Copyright

Copyright © 2009, Resilience Corporation

World-wide copyright reserved. No part of this publication may be stored in a retrieval system, transmitted, or reproduced in any way, including but not limited to photocopy, photograph, magnetic, chemical, or other record, without the prior agreement and written permission of Resilience Corporation.

Websense is a registered trademark of Websense, Inc., in the United States and certain international markets. Websense has numerous other unregistered trademarks in the United States and internationally.

All other product names mentioned herein are trademarks or registered trademarks of their respective owners.